

## Icom IC-W32A QuickSheet™

© 2005-2012 by joel Sampson / N5LXI, All Rights Reserved

Select	Key(s)	Notes
Power	Hold [POWER] (2 sec)	toggles on / off
VFO mode	[VFO]	Band & VFO
Memory mode	[MR]	
Change section	[MAIN]	Left / Right
Band – UHF side	[BAND]	Low (VHF) / High (UHF) / OFF
Band – VHF side	[BAND]	Low / High / WEATHER / OFF
Alpha / Freq Display	[M-N]	Toggles
Display transmit frequency	Hold [SQL]	
Lock	Hold [CALL] (2 sec)	Locks the knobs
Guide (help) mode	Hold [L/G] (below PTT), press a key	Lights and scrolls help
<b>Set</b>		
Frequency	[VFO], enter via keypad or turn knob	VFO mode only
Tone (turn on CTCSS)	[TONE]	Same as B key.
Set CTCSS Tone freq	[H/L] (2 sec), [TONE] until RT displays, select tone with DIAL, [PTT] to set.	Must be in Tone mode
Offset (+/- repeater split)	Hold [TONE] (2 sec)	- DUP/DUP (+)/None (blank)
Tone search (in Tone mode)	Hold [T SCAN] (2 sec)	Same as # key.
Transmit power level	[H/L]	Blank (High) or LOW, "A" key
Squelch level	Hold [SQL], set with knob, [PTT] to set	[SQL] is above the [PTT]
<b>Memory</b>		
Memory store (in VFO mode)	[S.MW], select location w knob, Hold [S.MW] (2 sec)	Press [S.MW] briefly!
Transfer Memory to VFO	Select channel, hold [S.MW] (2 sec)	
Directly go to a memory	Enter two digit number on the keypad	
<b>Scanning</b>		
Scan Mode	Hold [MAIN] (2 sec)	Either VFO or Memory mode
Skip memory channel	Select memory, Hold [MR] (2 sec)	Toggles "S"kip

**Verified Dallas/Fort Worth repeater list and More at [www.N5LXI.com](http://www.N5LXI.com).**

Please e-mail me any corrections or comments from my web site.

Last Revised: 06/25/12